

## Step 1

ProPower Gold Marine Engine is delivered in a durable polymer shipping container. Upon receipt, check for any damage to outside of container.



## Step 2

Open up the container and check the contents:


- 1) Marine Long Block
- 2) Gasket Set
- 3) Oil Pump
- 4) Warranty paperwork

Ensure that there is no damage to the engine.



## Step 3

Once engine is removed from it's container, remove all packaging materials (plastic wrap, etc.). Separate all three parts of the container and wipe down all surfaces.



## Step 4

Insert the engine rack into the bottom tray. Pull the engine strap tight. Place the bottom tray with the engine rack into the top cover. Hook the bungee cords over the edges of the tray. Call 1-800-PICK-UPS or log on to [www.ups.com](http://www.ups.com) to arrange for UPS to pick up the carton, OR take the container to a local UPS drop-off point for return shipment. A \$60.00 credit will be issued upon receipt.

**NOTE: It is most cost effective for you to ship the container as described above and depicted below. NOT AS DEPICTED IN STEP 1.**



Return to:  
BASIC POWER IND.  
177 FULFORD DR.  
HARKERS ISLAND,  
NC 28531